

interbois

Interior finishing. Elevated.

8518

2D Barnwood Installation guide



Dimensions:
9/16" et 13/16" x 5-5/8"
Lengths: **2' à 5'**

Coverage:
16,94 sq ft per box

Specie:
knotty pine

Finish:
stainless white and copper

Installation:
interior only



Materials required

- Masking tape
- Level
- Chalk line
- Mitre saw
- Table saw
- PL construction glue
- Glue gun
- Finishing nailer
- 18 gauge finishing nails



Recommendations and warnings

- ▶ Allow the material to acclimatize flat to its new environment for 48 to 72 hours before installation. Do not store 2D barnwood for long periods of time in an unheated basement or garage.
- ▶ The product may have lighter vertical marks. These are marks left by the drying of the wood and are part of the product.
- ▶ When purchasing your material, allow about 10% for waste (if cutting is necessary).
- ▶ 5% imperfection is considered acceptable for each package. This percentage does not include cutting waste.
- ▶ The pieces may appear about 1/16" apart in drier weather.



Preparing the work environment

- ▶ Check the condition of the work surface before starting any installation procedure for 2D barnwood.
- ▶ Remove any remaining glue, nails or other materials that could interfere with installation, and level off the surface by correcting any unevenness as necessary.



Before you start

- ▶ Make sure you have good lighting.
- ▶ First, draw up a clear, detailed plan to ensure installation is accurate and consistent and make sure you have sufficient materials for the entire project.
- ▶ Inspect all boards thoroughly before installation.
- ▶ Carefully select boards to create a representative layout of the final result. Design an assembly that coordinates variations in length and thickness.
- ▶ If you have any doubts about the product, its workmanship or its finish and can't place it in a less conspicuous area or eliminate imperfections, don't install it. Once the product has been installed, it is considered accepted by the installer and/or owner even if the owner is absent at the time of installation.
- ▶ Make sure the product you purchase is suitable for the desired installation.
- ▶ First check whether the installation requires the addition of finishing mouldings such as 8435 or baseboards at the bottom of the walls. If so, allow for the required spacing.

Installation steps

Installing 2D barnwood should be the last step in any construction or renovation project.

▶ Step 1

Use a chalk line to draw a horizontal line ¼" from your floor. Make sure it's level.

▶ Step 2

Apply a ½" bead of glue all around the back of your board. Place it on the surface with the female side down, making sure to place it along the line drawn.

▶ Step 3

Secure the board permanently with finishing nails.

▶ Step 4

Repeat steps 2 and 3 on the desired surface. Check that the boards are level after each row.

For full product warranty details, including all specifications and warnings, go to interbois.ca

